

Q.1 The chipset provides an extension of the data bus and address bus to the expansion slots. (complete)

Q.2 IBM settled on a standard expansion bus speed of about 7 MHz, 33MHz than the CPU! (complete)

↑
which is slower

Q.3 An AGP slot is a PCI slot, but one with a direct connection to the Northbridge. (complete)

Q.4 What is PCI stands for... Peripheral component interconnect

Q.5 List three types of system resources:

- a. DMA (direct memory access)
- b. I/O address
- c. memory

10

Q.6 List two types of the false starts expansion buses:

- a. MCA (micro channel architecture)
- b. EPCI (extended PCI)
- VL-bus